

# Installation Instructions

Frymaster 1814/Dean SCFS

*SuperSorb*  
CarbonPads

## Getting the most out of your frying program



**1)** Open the fryer doors and pull the filter pan out. Be sure filter pan is clean and dry. Place the screen on the bottom of the pan. The holes of the screen should line up with the posts on the bottom of the pan.



**2)** Insert the F-69 CarbonPad (15.875" x 18.875") into the pan with the bumpy side up (smooth side down).



**3)** Insert the existing hold down ring and press it firmly into place. (F-69 Carbon Pad not shown in photo.) Place the crumb catcher on top of the hold down ring.



Frymaster 1814/Dean SCFS fryers should be filtered twice a day, after lunch and after dinner. Once filter pan has cooled from first filtration, scrape crumb debris off the CarbonPad as shown in photo. Removing crumb debris will improve oil return to fryer.

Frymaster 1814/Dean SCFS filter pan, crumb tray, hold down ring, and support screen.



**FILTERCORP**

9805 NE 116th Street  
PMB A-200  
Kirkland, WA 98034  
USA

Toll Free: (800) 473-4526  
Telephone: (425) 820-4850  
Fax: (425) 820-2816  
Web: [www.filtercorp.com](http://www.filtercorp.com)



[www.filtercorp.com](http://www.filtercorp.com)