

# Installation Instructions

Dean MF 80/90

# SUPERSORB<sup>®</sup> CARBONPADS



**1)** Make sure the bowl of the machine is clean and dry before you can start to assemble the machine back together. Place the screen at the bottom.



**2)** Place the filter on top of the screen ensuring the smooth side is facing down and the bumpy side faces up. Place the ring on top of the filter.



**3)** Make sure to tighten the handles from the ring to the sides of the machine. Reconnect the hose to the machine.



**4)** Using a metal spatula, gently remove crumb debris from the top of the filter, this will help oil flow through the filter for daily 2nd filtration as well removal of the filter.



**5)** Disconnect the hose from the machine and set aside, then remove the ring from the top of the filter and set aside.



**6)** Remove the used filter and discard.



**7)** Remove the bottom screen of the machine. Rinse and clean out the bowl only using HOT water at the dish area or mop sink.

Filtercorp CarbonPad F-38 is 16.25" x 18.25".

Always wear protective apparel (face shield, heat resistant gloves, and vinyl apron) when filtering hot oil.



## FILTERCORP

9805 NE 116th Street  
PMB A-200  
Kirkland, WA 98034  
USA

Toll Free: (800) 473-4526  
Telephone: (425) 820-4850  
Fax: (425) 820-2816  
Web: [www.filtercorp.com](http://www.filtercorp.com)



[www.filtercorp.com](http://www.filtercorp.com)