

Installation Instructions

Frymaster (Built-in) FootPrint III Filtration System

SUPERSORB[®] CARBONPADS

Getting the most out of your frying program



- 1)** Open the fryer doors and pull the filter pan out. Remove weight ring, but leave the screen in place at the bottom of the well.



- 2)** Insert the F-54 CarbonPad into the pan with the bumpy side up. The CarbonPad will fit "edge to edge."



- 3)** Insert the hold down ring and press it firmly into place. Finally, insert the crumb catcher.



 **FILTERCORP**

9805 NE 116th Street, PMB A-200
Kirkland, WA 98034 USA
Web: www.filtercorp.com



www.filtercorp.com