

# Installation Instructions

Frymaster (Built-In) FootPrint Pro Filtration System

# SUPERSORB<sup>®</sup> CARBONPADS

## Getting the most out of your frying program

- 1)** Open the fryer doors and pull the filter pan out. Remove weight ring, but leave the screen in place at the bottom of the well.



- 2)** Insert the F-33 (14.75" x 22") or F-54 (14.125" x 21") CarbonPad into the pan with the bumpy side up. Be sure the CarbonPad is centered over the well.



- 3)** Insert the new Frymaster hold down bar, 810-2909 as shown, or 810-3946 Hold down ring and press it firmly into place. Insert crumb catcher, remember to scrape the crumbs off the CarbonPad for multiple fryer filtrations.



## FILTERCORP

9805 NE 116th Street  
PMB A-200  
Kirkland, WA 98034  
USA

Toll Free: (800) 473-4526  
Telephone: (425) 820-4850  
Fax: (425) 820-2816  
Web: [www.filtercorp.com](http://www.filtercorp.com)



[www.filtercorp.com](http://www.filtercorp.com)