

Installation Instructions

Henny Penny Open Vat & Pressure Fryer Installation Guide

SUPERSORB[®] CARBONPADS

Getting the most out of your frying program



- 1)** First, please remove the original filter screen and filter assembly from the Henny Penny filter tank.



- 2)** Replace with Filtercorp Unifit Adapter Kit #752 which includes the CarbonPad base with handle, 17" NSF hose, and coupler fitting.

- 3)** Be sure to place CarbonPad with rough side facing out, smooth side against the adapter base screen support.



- 4)** Make sure 17" Hose is tightly screwed onto the CarbonPad base and coupler fitting. The CarbonPad Adapter is now ready to screw into the Henny Penny wing nut coupler.



- 5)** After filtering all fryers, carefully scrape the crumb debris off the CarbonPad using a spatula or putty knife. The CarbonPad is now ready to filter fryers for the day's 2nd filtration. Always use a new CarbonPad every day.



FILTERCORP

9805 NE 116th Street
PMB A-200
Kirkland, WA 98034
USA

Toll Free: (800) 473-4526
Telephone: (425) 820-4850
Fax: (425) 820-2816
Web: www.filtercorp.com



www.filtercorp.com