

Installation Instructions

Frymaster PF 50

SUPERSORB[®] CARBONPADS

Getting the most out of your frying program

- 1)** Before assembling the filter pan unit, be sure to clean and dry any water in the pan. Place the support screen in the center of the pan.



- 2)** Insert the F-20B CarbonPad into the pan with the bumpy side up (smooth side down).



- 3)** Insert the existing hold down ring and press it firmly into place.



- 4)** WHEN NEEDED, scrape the crumb debris off the CarbonPad before continuing the oil filtrations. Please allow filter pan to cool before scraping CarbonPad. Removing crumb debris will help oil flow back to the fryer vats. Use one CarbonPad and replace at start of each day.



The F-20B CarbonPad[®] dimension is 12.375" x 17.375" (12 3/8" x 17 3/8").

Always wear protective apparel (face shield, heat resistant gloves, and vinyl apron) when filtering hot oil.



FILTERCORP

9805 NE 116th Street, PMB A-200
Kirkland, WA 98034 USA
Web: www.filtercorp.com



www.filtercorp.com