

# Installation Instructions

RF Hunter Portable Filter Machine – Starter Kit# 723-40

# SUPERSORB<sup>®</sup> CARBONPADS

## Getting the most out of your frying program



- 1)** Remove any existing screens, paper holders, etc. from the filter pan.
- 2)** Locate the front of the pump housing. Remove the 1046 coupling from the housing pump pipe. Install the 1/2" 90 degree elbow (part# 867) and the 1/2" male quick disconnect (part# 1013).



- 3)** The Filtercorp Unifit adapter (part# 1001-40) will have a flexible stainless steel hose (part# 1064) with a bushing (part# 1007), 1/2" female quick disconnect (part# 1016) and standard handle (part# 1005).



- 4)** Place the Filtercorp Unifit into the RF Hunter pan so that it sits flush with the bottom of the pan. Connect the female quick disconnect on the end of the hose with the male quick disconnect located on the pump housing. You are now ready to filter.

**NOTE:** Install the CarbonPad with the smooth side against the screen, bumpy side out.



## FILTERCORP

9805 NE 116th Street, PMB A-200  
Kirkland, WA 98034 USA  
Web: [www.filtercorp.com](http://www.filtercorp.com)



[www.filtercorp.com](http://www.filtercorp.com)