

Installation Instructions

Restaurant Technology Inc.

SUPERSORB[®] CARBONPADS

Getting the most out of your frying program



- 1)** Before assembling the filter pan unit, be sure to clean and dry any water in the pan. Place the support screen in the center of the pan.



- 2)** Insert Filtercorp CarbonPad[®] into the pan with the bumpy side up (smooth side down).



- 3)** Place 4 hold down weights and press firmly next to edge of all 4 sides.



- 4)** Place grid cover and crumb basket on filter bucket. Place motor housing over open end and insert bucket hose to motor quick connection. Insert long hose to pump quick connection. Insert long hose to pump quick connect (photo not shown).



- 5)** WHEN NEEDED, scrape the crumb debris off the CarbonPad[®] before continuing the oil filtrations. Please allow filter pan to cool before scraping CarbonPad[®]. Removing crumb debris will help oil flow back to the fryer vats. Use one CarbonPad and replace at start of each day.

*The F-68A CarbonPad[®] (large RTI filter machine) is 18.25" x 25.5".
F-81 CarbonPad[®] (small RTI filter machine) is 15" x 21".*

Always wear protective apparel (face shield, heat resistant gloves, and vinyl apron) when filtering hot oil.



FILTERCORP

9805 NE 116th Street, PMB A-200
Kirkland, WA 98034 USA
Web: www.filtercorp.com



www.filtercorp.com