

# Installation Instructions

Pitco Bloomin Brands

# SUPERSORB<sup>®</sup> CARBONPADS

## Getting the most out of your frying program



- 1)** Open the fryer doors and pull the filter pan out. Be sure filter pan is clean and completely dry of water. Place the screen on the bottom of the pan.



- 2)** Check Pitco Strainer Cap and clean off any crumb debris.



- 3)** Insert the F-87 CarbonPad (19.16" x 19.16") into the pan with the bumpy side up (smooth side down).



- 4)** Insert the existing hold down ring and press it firmly into place.

(continued)

# Installation Instructions (continued)

**SUPERSORB<sup>®</sup>**  
**CARBONPADS**

Pitco Bloomin Brands



- 5)** For multiple filtrations, when filter pan has cooled, using a spatula scrape crumb debris off the CarbonPad as shown in photo. Removing crumb debris will improve oil flow through the filter and back to fryer.



- 6)** Preventative maintenance includes replacing the O-ring which is located inside the Pickup pipe opening usually once a year. Pitco Part Number is 60068301. O-rings in good condition help create a tight seal to the pipe arm and Filtercorp CarbonPad filter.

Always wear protective apparel when filtering hot oil which includes heat resistant gloves, face shield, and vinyl apron.



COMMERCIALLY  
COMPOSTABLE ONLY.  
FACILITIES MAY NOT  
EXIST IN YOUR AREA.  
CERT #10528900



## **FILTERCORP**

9805 NE 116th Street  
PMB A-200  
Kirkland, WA 98034  
USA

Toll Free: (800) 473-4526  
Telephone: (425) 820-4850  
Fax: (425) 820-2816  
Web: [www.filtercorp.com](http://www.filtercorp.com)



[www.filtercorp.com](http://www.filtercorp.com)