

# Installation Instructions

Pitco P14/P18 Portable Filter Machine

# SUPERSORB<sup>®</sup> CARBONPADS



**1)** Be sure filter pan is completely dried of water.



**2)** The Support Wire Grid must be centered so there is equal space from the front and the back of filter pan.



**3)** Place CarbonPad's bumpy side up, smooth side down in filter pan.



**4)** Clamp Hold Down Bar in rear and front of filter pan.



**5)** Securely connect hoses with quick disconnects.



**6)** If using the cover, place crumb basket in the open area.



**7)** For heavy crumbs and multiple fryer filtering, after the machine has cooled, remove crumb and flour debris using a spatula or other scraper tool. Oil flow will be improved for additional use.

F-94 CarbonPad, 13.37" x 23.87", used for P14 model  
F-96 CarbonPad, 17.5" x 27.875", used for P18 model

*Always use protective apparel when handling hot oil.*



## FILTERCORP

9805 NE 116th Street  
PMB A-200  
Kirkland, WA 98034  
USA

Toll Free: (800) 473-4526  
Telephone: (425) 820-4850  
Fax: (425) 820-2816  
Web: [www.filtercorp.com](http://www.filtercorp.com)



[www.filtercorp.com](http://www.filtercorp.com)